




Step 1: Making rib 'Bow-C'





1. Cut 57mm disk from 0.080" plastic. Drill 5/16" hole offset from center by 12.5mm as shown.



2. Cut off 12mm-high segment as shown. Do not discard.




3. Glue the previously-cut segment to the other side as shown, edges flush.






4. Completed rib 'Bow-C'

Step 2: Making rib 'Bow'





Cut 32mm disk from 0.080" plastic. Drill 5/16" hole in center.


Step 3: Assembling 'Bow'



Step 4: Skinning 'Bow'



Step 5: Installing 'Bow'



Glue the entire 'Bow' assembly to the front of bulkhead C, so the top center of rib 'Bow-C' is 12mm from top of the bulkhead.